

HOW TO INSTRUCTIONS

HAMMOCK

1. Start by taking your hammock out of the bag, making sure you have your carabiners and both Talon Straps to hang up with!



2. Find two trees 10-12 feet apart that can support the hammock and its occupants. Make sure they look sturdy so you don't harm the trees!



3. Wrap one strap 1-2 times around the first tree approximately 5 feet up from the ground, pass the end with one loop through the other end.



3. Attach a carabiner to a loop on the adjustable end of the strap and make sure the carabiner's gate is fully closed.



4. Repeat the process for the other strap. Adjust up or down to your liking! Hammock should hang at least 18" from the ground.



5. Enter the hammock by spreading the fabric wide, taking a small step back, and sitting down. Swing your legs in!



HOW TO INSTRUCTIONS

UNDERQUILT

1. Start by unpacking your underquilt, taking it out of the stuff sack and shaking it open to air it out.



2. Pass the pull cords on one end over one another and in to the carabiners you use to hang your hammock.



3. Do the same to the other side, and then get your hammock situated nicely in the underquilt, tightening as needed.




3. We've included center pull cords for easy adjustment of the fit on your Flare, a sure way to get that snug fit even from inside your sleeping bag.



HOW TO INSTRUCTIONS

BUG NET

1. Tie the ridge line of your Bug Net one foot above your hammock straps, then do the same to the other side so it's taught and roomy.



2. Unclip one of your carabiners and then slide your hammock through. Reattach your carabiner and tighten the pull cords on either end.



3. Hang the attached clips to the ridge line and make sure there's plenty of room inside. Unzip and climb in for bite free hammocking!



HOW TO INSTRUCTIONS

RAIN FLY

1. Start by unpacking your Rain Fly, make sure that you have the lines, slides, and everything you need to hang safe and dry.



2. Tie the ridge line to both trees about one foot over the hammock straps. Make sure the center of the tarp is a few feet above the straps.



3. Tie your lead lines to the included stakes and pull the easy tighteners. Just make sure to leave enough room underneath to be comfortable!



3. With your included stakes drive the lines tight into the ground to give yourself maximum head room. You can also lift the edges up on trekker poles!



HOW TO INSTRUCTIONS

SLING SEAT

1. Start by taking your Sling Seat out of the bag, make sure you have the seat, two cushions, carabiners, and your center 'kick back' strap



2. Wrap your Talon Straps around two trees and connect the Kick Back strap. Use carabiners to clip both loops on either side.



3. Tighten the buckles on your Kick Back strap by pulling on them toward the center of the strap. This will make for a tight center line.



3. Clip your seat to the loops on your 'Kick Back' strap. There are sixteen connection points marked with our 'Kick Back' or 'Sit Up' patches.



4. Once you've got your Sling Seat hanging you can slide in our pressure point comfort cushions, or add in your favorite hoodie for that extra bit of plush.



5. Remember you can always adjust the angle of your seat, just clip the ends wider to 'Sit Up', or bring them closer in for a 'Kick Back' experience.



HOW TO INSTRUCTIONS

DRY BAGS

1. Start by placing your gear into the open dry bag, making sure you're not putting in any sharp objects like tent stakes or open pocket knives.



2. Once you have all your gear stowed take the top of your bag and roll it 3 to 5 times tightly, making sure there isn't too much air trapped inside.



3. With your bag top rolled clip the ends together to keep everything secure and water tight. Use the D ring to tie it off to your boat!



HOW TO INSTRUCTIONS

FOOT PRINT

1. Start by unpacking your Big Foot, and take care to notice how it's folded for easy storage when you're ready to go.



2. Lay your foot print out on a wide, level, and hazard free piece of ground. Avoid dips that may collect water, sticks, and rocks.



3. Once you've got your Big Foot spread out get ready to stake it down. Find your stakes and clear the area.



3. With your included stakes pull one corner tight and drive the stake through the open looped end, not the metal grommet, then repeat.



4. Use the metal grommets to secure your tent poles, passing them first through the connections on the tent, and then finally into the grommets.



5. Enjoy your footprint as a dry, dirt free place to place your boots, backpack, or any other goods. Keep it clean, and fold it neatly when you're ready to go!



HOW TO INSTRUCTIONS

HAMMOCK SLEEVE

1. Start by unpacking your Hammock sleeve, removing it from the bag and taking it over to your hammock.



2. Unclip the carabiners on one side of your hammock and slide hammock sleeve over, like rolling up a sock until it's all covered.



3. Use the easy tighteners to adjust the fit of the hammock sleeve, opening one end when you want to hang and sliding in or out of the way!



HOW TO INSTRUCTIONS

WAIST BAG


1. Strap your waist bag securely around your hips, pulling it tight so it's comfortable.



2. Once your waist bag is secure open the top velcro flap then unroll the sealed layers to get inside.



3. Place your valuables in the bag where they'll stay dry, and make sure to roll the top before sealing the velcro.



HOW TO INSTRUCTIONS

PHONE CASE

1. Open your Wise Owl Phone Case with the locking rollers, using the easy thumb tabs to gain access.



2. Place your valuables in the bag where they'll stay dry, and make sure to roll the locks closed before hand!



3. With your device stowed safely in its' case make sure you keep the lanyard tight so everything stays secure!



HOW TO INSTRUCTIONS

COOLER BAG

1. Start by placing your food or drinks into the open bag, save room for layers of ice that will keep your lunch cool!



2. Once you have all your food stowed take the top of your bag and roll it 3 to 5 times tightly, then let air in with your valve.



3. With your bag top rolled clip the ends together. Tighten your straps for an easy carry on the beach or trail.



HOW TO INSTRUCTIONS

HOMEBODY

1. Hang your Homebody with the included S hook. Attach your hook to a point in a stud or beam for strength.



2. Check the strength of your connection by lightly placing your weight and never jump into your chair or exceed limitation.



3. With your chair hung safely make sure to enjoy it responsibly, maximizing your fun and quality time with the family!

